

# How to Install

## An Acrylic Door Handle



- 1 Unbox the handle.
- 2 Line up the handle around the door handle pocket.
- 3 Mark with pencil or other tool where to drill in screws.
- 4 Place screws into handle onto cooler and drill them in one at a time.



**Need some help?**

**P: 715.386.2233**

**E: [contact@cantaloupe.com](mailto:contact@cantaloupe.com)**